

PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE

Copy Certificate

Certificate Reference Number 01/24

DETAILS OF CLIENT

Client/ Address: The Redbridge Music Lounge
28 Grosvenor Gardens Woodford Green Essex IG8 0BE

TEST EQUIPMENT DETAILS

Test Equipment used PSS BATTPAT Serial Number PASS12252327
Tested by Chris Wyatt Date 1.1.2024 Retest Date 1.1.2025

Serial Number	Make and model	Class I Class II	(V)	(A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body OK ?	OK to use ?
WPBX02278	Yamaha NP 30	II	12		3	y	y	y	y
P0349266334	JBL EON 10 GS/230	I	240		13	y	y	y	y
P034926807	JBL EON 10 GS/230	I	240		13	y	y	y	y
km 54019	Line 6 Lowdown	I	240		10	y	y	y	y
30512059	Line 6 Spider 111 30	I	240		10	y	y	y	y
001	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
wwm11001527	Wharfdale wireless	II	12	1.25	5	y	y	y	y
A1A1538	Roland Cube Street	II	9	2	5	y	y	y	y
A0A1436	Roland Cube Street	II	9	2	5	y	y	y	y
CZ81328	Roland Cube Street	II	9	2	5	y	y	y	y
PASS12252327	PAT TEST KIT BATTPAT	I	12	500ma	5	y	y	y	y
N89	YAMAHA STAGEPAS	I	240		5	y	y	y	y
CRC 57017	Saturn Laminator	I	240	2	4	y	y	y	y
012582	ZOOM VIDEO	II	5	1	-	y	y	y	y
A31108108913	ALESIS DRUM PADS	II	9	720ma	5	y	y	y	y
002	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
003	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
004	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
005	Mains Block 4 way Wh	I	249	13	13	y	y	y	y
006	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
007	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
008	Mains Block 1 way Wh	I	240	13	13	y	y	y	y
LEDJ LiiMix	4ch light mixer	II	12	300ma		y	y	y	y
KAM Light	controller	I	240	5	5	y	y	y	y
0052000128	Sennheiser radio Mic	II	12	300ma	5	y	y	y	y
009	IEC lead Wh	I	240	13	5	y	y	y	y
010	IEC lead Grey	I	240	13	10	y	y	y	y
011	IEC lead Bck	I	240	13	5	y	y	y	y
012	IEC lead Blk	I	240	13	5	y	y	y	y
013	IEC lead 2 pin Blk	II	240	13	5	y	y	y	y
CR330684	SWR Redhead Bass amp	I	240	13	13	y	y	y	y
016	Mains Block 8 way Wh	I	240	13	13	y	y	y	y
017	Mains Block 8 way Wh	I	240	13	13	y	y	y	y

13414	MK 16amp RCD box	I	240	13	13	y	y	y	y
018	MK16A Ext Cable K9024	I	240	13	13	y	y	y	y
019	Ext block 16A 4 way Wh	I	240	13	13	y	y	y	y
020	Ext block 16A 4 way Wh	I	240	13	13	y	y	y	y
021	Adaptor 16A -13A	I	240	13	13	y	y	y	y
AU0002AA121003	Fohnn XE20 pa amp	I	240	13	13	y	y	y	y
022	Ext block 16A 4 way Blk	I	240	13	13	y	y	y	y
023	30m Ext Reel Blue	I	240	13	5	y	y	y	y
H201004	Yamaha Graphic eq	I	240	13	3	y	y	y	y
2908035	K Array Redline PA amp K1 12	I	240	13	5	y	y	y	y
2908027	K Array Redline PA amp K1 12	I	240	13	5	y	y	y	y
AOE9639	Roland Street Box CW	II	9	2	5	y	y	y	y
026	Ext block 4 way Wh	I	240	13	13	y	y	y	y
027	Ext block 4 way Wh	I	240	13	13	y	y	y	y
030	Mains Reel 25m Red	1	240	13	13	y	y	y	y
031	16A ext Lead Blue	I	240	13	5	y	y	y	y
032	IEC lead Blk	I	240	13	5	y	y	y	y
033	Mains Block 4 way Wh	I	240	13	13	y	y	y	y
034	IEC lead Blk	I	240	13	5	y	y	y	y
035	IEC lead Blk	I	240	13	5	y	y	y	y
036	IEC lead Blk	I	240	13	5	y	y	y	y
L39300980	DB Flexis monitor spk	I	240	2	5	y	y	y	y
L39300981	DB Flexis monitor spk	I	240	2	5	y	y	y	y
037	Mains Block 4 way Wh	I	240	13	10	y	y	y	y
5112362245	Peavey Acoustic Amp	L	240	13	5	y	y	y	y
N150142	Pedal power IS05	I	240	13	13	y	y	y	y
410599	Radial Tonebone Pre Z	II	15	400ma	-	y	y	y	y
S13-00652	Strymon Trem Rev Pedal	II	9	2	-	y	y	y	y
N0001002	Yamaha MX12/4	I	240	13	13	y	y	y	y
5039180	Stagg Pro mix amp	I	240	13	13	Y	Y	Y	y
038	Mains block x4 wh	L	240	13	13	Y	Y	Y	y
039	Mains block x4 wh	L	240	13	13	Y	Y	Y	y
040	Mains block x2 wh	L	240	13	13	Y	Y	Y	y
041	Mains block x2 wh	L	240	13	13	Y	Y	Y	y
042	Mains block x4 wh	L	240	13	13	Y	Y	Y	y
A850598	Fender Champ Amp	I	240	13	5	Y	Y	Y	y
043	Mains block x 2 wh	I	240	13	5	Y	Y	Y	y
EBVL01530	Yamaha P45 Keyboard	II	12v	1.5	3	Y	Y	Y	y
03017250029	Fame Personal Monitor	I	240	13	5	Y	Y	Y	y
BBUN01020	Yamaha NP31S Keyboard	II	12v	1.5	3	Y	Y	Y	y
044	IEC Lead Black	I	240	13	5	Y	Y	Y	y
045	IEC Lead Black	I	240	13	5	Y	Y	Y	y
046	Mains block x4 wh	L	240	13	13	Y	Y	Y	y
047	Mains Lead 2 pin	I	240	13	5	Y	Y	Y	y
048	Mains block x4 wh	L	240	13	13	Y	Y	Y	y
099	Oakcastle CD10 adaptor	II	5v	-	-	Y	Y	Y	y
050	4.5v adapter	II	4.5v	-	-	Y	Y	Y	y
052	Mains block x4 wh	L	240	13	13	Y	Y	Y	y
053	IEC Lead Grey	I	240	13	5	Y	Y	Y	y
054	Ikea Flexlight	II	3.5	700ma	-	y	y	y	y

055	Ikea Flexlight	II	3.5	700ma	-	y	y	y	y
056	IEC Lead Black	I	240	13	5	Y	Y	Y	y
057	Micro Pog FX pedal	II	9v	-	-	Y	Y	Y	y
058	IEC Lead Black	I	240	13	5	Y	Y	Y	y
QCA 1092	Laney VC 15 110 Amp	I	240	13	5	Y	Y	Y	y
QL45988	Hitachi Projector	I	240	13	5	Y	Y	Y	y
BID 12 VVVV	HP Compac Pro 4300 Computer	I	240	13	5	Y	Y	Y	y
9029902	Sony Monitor KDL3053000	I	240	13	5	Y	Y	Y	y
10586	Warm music GTR Amp	I	240	13	5	Y	Y	Y	y
060	Mains block 2x2 wh	L	240	13	13	Y	Y	Y	y
062	Mains block 4 way wh	L	240	13	13	Y	Y	Y	y
063	Mains block 4 way blk	L	240	13	13	Y	Y	Y	y
064	IEC Lead Black	I	240	13	13	Y	Y	Y	y
0645G	Mains Adaptor	II	12v	1.25a	-	Y	Y	Y	y
067	HK Adaptor 0950BS	II	9v	4.5	-	Y	Y	Y	y
2003200208H	Marshall MD30 OFX Combo	I	240	13	5	Y	Y	Y	y
BBTN0130	YAMAHA P105 PIANO	II	12v	1.5	-	Y	Y	Y	y
0220383	TEAC CD player	I	240	13	3	Y	Y	Y	y
VQU16CX673752	A&H QU16 Mixer	I	240	13	3	Y	Y	Y	y
068	Mains Block x8 8 wh	I	240	13	13	Y	Y	Y	y
V22182121	QSC K8.2 amp	I	240	2.1	5	Y	Y	Y	y
VCH0V0696	QSC K8.2 amp	I	240	2.1	5	Y	Y	Y	y
069	Mains Block x4 wh	I	240	13	13	Y	Y	Y	y
070	IEC Lead Black	I	240	13	13	Y	Y	Y	y
071	IEC Lead Black	I	240	13	13	Y	Y	Y	y
072	Mains Block x4 wh	I	240	13	13	Y	Y	Y	y
073	Mains Block x4 wh	I	240	13	13	Y	Y	Y	y
6402569579	Peavey KB199	I	240	13	5	Y	Y	Y	y
KAA10042	Kustom amp	I	240	13	5	Y	Y	Y	y
074	IEC Lead Black	I	240	13	13	Y	Y	Y	y
075	Mains block ext 2 way wh	I	240	13	13	Y	Y	Y	y
076	Mains block ext 4 way blk switched	I	240	13	10	Y	Y	Y	y
A5J2163	Boss Vocal Echo	II	9v	600ma	-	Y	Y	Y	y
079	IEC Lead Black	I	240	13	13	Y	Y	Y	y
694318000854	Alesis Microverb	II	9v	-	-	Y	Y	Y	y
080	Mains Block x 6 wh	I	240	13	13	Y	Y	Y	y
C0B2522	Roland Cube 40XL	I	240	13	5	Y	Y	Y	y
OJBU130224	Trace Elliot ELF	1	240	13	-5	Y	Y	Y	y
082	IEC Lead Black	I	240	13	13	Y	Y	Y	y
083	IEC Lead Black	I	240	13	13	Y	Y	Y	y
084	Mains Block x 6 blk	I	240	13	13	Y	Y	Y	y
085	Waterproof ect lead yellow	I	240	13	13	Y	Y	Y	y
015056	Waterproof reel 20m yellow	I	240	13	13	Y	Y	Y	y
CNF9112022	HP Presario Laptop	I	19.5v	1.5a	3.5a	Y	Y	Y	y
2008/10	Eastcoast 20GA Amp	I	240	13	5	Y	Y	Y	y
059631	KPA3 Yamaha Adapter	II	11.5	600ma	-	Y	Y	Y	y
SWU20L	Swan Kettle Urn	I	240	13	13	Y	Y	Y	y
EBZMO1268	Yamaha NP32 Keyboard	II	12v	1.5.a	-	Y	Y	Y	y
658033459	PA-150/B 12v	II	12v	1.5a	-	Y	Y	Y	y
2DA2012EK	KTEX AC adaptor	II	12v	125ma	-	Y	Y	Y	y

14616LD	Russell Hobbs Kettle	1	240	13	13	Y	Y	Y	y
1387	Schertler combo	1	240	630ma	10	Y	Y	Y	y
SN14781B2A	Hannsprees PAD	II	5v	2.5a	-	Y	Y	Y	y
0502500EU	Hannsprees PAD	II	5v	2.5a	-	Y	Y	Y	y
088	Mains Block 4 way White	1	240	13	13	Y	Y	Y	y
089	IEC Lead Black	1	240	13	10	Y	Y	Y	y
090	IEC Lead Black	1	240	13	10	Y	Y	Y	y
091	Mains Block 4 way White	1	240	13	13	Y	Y	Y	y
07016	Russell Hobbs Kettle	1	240	13	13	Y	Y	Y	y
PL060040065	Yamaha Graphic EQ module	1	240	2.5	5	Y	Y	Y	y
AX1049907	Squire SP10	1	240	13	5	Y	Y	Y	y
TG25A	Novanex ID30	1	240	13	5	Y	Y	Y	y
Z6C2987	Roland Street Box (JP)	II	9	2	5	y	y	y	y
68752/882/530	Clarke 1KVA inverter gen	I	240	13	13	y	y	y	y
ZW45278	Roland Cube Street	II	9	2	5	y	y	y	y
HCA160410073	Blackstar Combo Amp	I	240	13	5	Y	Y	Y	y
36120-0018520	AC adapter	II	12v	2.0a	-	Y	Y	Y	y
S19100286957	Eurovive 8205 monitor Spk	I	240	13	3	Y	Y	Y	y
FM10709	Mains Cable 2pin	I	240	13	3	Y	Y	Y	y
17X0139	Tascam DP328 D	II	12v	1000ma	-	Y	Y	Y	y
ODKA	Linksys Ethernet hub	II	7.5v	700ma	-	Y	Y	Y	y
SM494U004	Safemore Tower plugboard	I	240	13	13	Y	Y	Y	y
1346-23	Numark MP102 CD/MP3	I	240	13	3	Y	Y	Y	y
YM5152M6RU3	Apple PowerMac G5	I	240	13	5	Y	Y	Y	y
CZC3284LR5	HP computer	I	240	13	5	Y	Y	Y	y
FW04098	Edirol 4A25	II	5v	1	-	Y	Y	Y	y
LYC170230112	Miditech Pianobox	II	5v	1	-	Y	Y	Y	y
HPA 4	Fame Headphone Splitter	II	12v	1	-	Y	Y	Y	y
TPA3116	Fosi Audio Mini Amp	II	12v	1	-	Y	Y	Y	y
S210301522AM	Beringer Mini Mixer	II	18.5	250ma	-	Y	Y	Y	y
E7VCA00625026	Benq Monitor Screen	I	240	1.5	5	Y	Y	Y	y
SP030A	Computer spks	II	9v	200ma	-	Y	Y	Y	y
V189455	Lenovo Monitor Screen	1	240	1.5	5	Y	Y	Y	y
JC03115131	Computer spks TGX -S2500	II	12v	1	-	Y	Y	Y	y
983QE	ACER Aspire X3200 Computer	I	240	3	5	Y	Y	Y	y
ETLAM0800E8E90	ACER Monitor Screen	I	240	1.5	5	Y	Y	Y	y
Z4ZEBKEB300207	Samsung PRINTER	L	240	2	5	Y	Y	Y	y
EN61558	Boss SE50	II	12v	1000ma	-	Y	Y	Y	y
EPP54	IBANEZ Wah WD7	II	14v	200ma	-	Y	Y	Y	y
1108563	10M NMains Reel Blue	I	240	13	13	Y	Y	Y	y
A3KM108	LCD Monitor Screen	1	240	1	5	Y	Y	Y	y
1420A	Amethyst Adaptor	II	14v	200ma	-	Y	Y	Y	y
092	IEC Lead Black	I	240	13	10	Y	Y	Y	y
1425200593	Line 6 Spider	I	240	2	5	Y	Y	Y	y
72475PD800142	Harley Bento Street	I	240	2	5	Y	Y	Y	y
0626-000610	Kustom Dart 10FX	I	240	100ma	5	Y	Y	Y	y
80051B	Switching P/S	II	12v	2500ma	-	Y	Y	Y	y
T0013	JBL EONOne	I	240	1	5	Y	Y	Y	y
BT1107102500196	Alesis 3632 Compressor	I	240	1400ma	5	Y	Y	Y	y
093	4 Way Mains Block White	I	240	13	10	Y	Y	Y	y

094	4 Way Mains Blok Wh switch	I	240	13	10	Y	Y	Y	y
21X0144	Tascam DP2450 Recorder	II	5v	200ma	-	Y	Y	Y	y
HN-238	HDMI Cam	II	5v	0.2a	-	Y	Y	Y	y
095	4 Way Mains Block White	I	240	13	10	Y	Y	Y	y
SM PBLP4Y	RCD mains ext Yellow	I	240	13	10	Y	Y	Y	y
096	4 Way Mains Block White	I	240	13	10	Y	Y	Y	y
097	IEC Lead Black	I	240	13	10	Y	Y	Y	y
098	4 Way Mains Block White	I	240	13	10	Y	Y	Y	y
092578	Netgear wifi	II	12v	1.5A	-	Y	Y	Y	y
3FV448801	Netgear wifi	II	12v	1.5A	-	Y	Y	Y	y
5127	Squire 15 guitar amp	I	240	1.5a	10	Y	Y	Y	y
07810858	Yamaha Monitor amp 100w	I	240	1.5a	10	Y	Y	Y	y
85006224	Crown XLS power amp	I	240	13	10	Y	Y	Y	y
15082473570	JBL Eon 610	I	240	13	10	Y	Y	Y	y
03690	CWT Ac adaptor	II	12v	2A	-	Y	Y	Y	y
B516101905	Alesis Nitro DM7Xelecdrums	II	9v	500ma	-	Y	Y	Y	y
100	Donner DED200 elec drums	II	9v	1A	-	Y	Y	Y	y

